



Warning: On two wheel drive trucks a clearance check must be performed when truck is loaded and unloaded to verify the inverted ball will not interfere with the top of the differential.

600 Series Installation Kits (Rated to vehicles Max Gross Weight Rating)

Make/Model	Style	Years From	Years To	Old Double-Lock Hitch#	New Double-Lock Hitch#	Old Quick Goose2 Hitch#	New Quick Goose2 Hitch#	Old Rail Kit#	New Rail Kit#	Notes
CHEVROLET/GMC										
1500 & 2500LD Silverado/Sierra	New Body, 69.3", 78.7" & 97.6" Beds	2007	2011	C-615	60615	n/a	n/a	C-632	60632	Z
	Classic Body Only	1999	2007	C-600	60600	C-630	60630	C-652	60652	Z
2500HD & 3500 Silverado/Sierra	Long & Short Beds	2011	2011	-	60607	n/a	n/a	-	60604	Z
	Classic & New Body	2001	2010	C-600	60600	C-630	60630	C-652	60652	Z,4
2500 & 3500	Old Body, Long & Short Beds	1999	2000	C-600	60600	C-630	60630	C-631	60631	Z
Full Size Pickup Trucks	Not 34" Frame (O.D.)	1988	1998	C-600	60600	C-630	60630	C-631	60631	Z
DODGE										
Ram 1500	All Beds, Including Mega & Crew Cab	2009	2011	C-600	60600	n/a	n/a	-	60657	Z
		2009	2010	C-600	60600	n/a	n/a	C-656*	60656*	Z
		2002	2008	C-600	60600	C-640	60640	C-659	60659	Z,1,2
				C-600	60600	C-640	60640	C-655*	60655*	Z,1,2
	All	1994	2001	C-600	60600	C-640	60640	C-635	60635	Z
Ram 2500 & 3500	All Beds, Including Mega Cab	2003	2011	C-600	60600	C-640	60640	C-659	60659	Z,1,2
		2003	2009	C-600	60600	C-640	60640	C-655*	60655*	Z,1,2
	All	1994	2002	C-600	60600	C-640	60640	C-635	60635	Z
FORD										
F-150	All Beds	2004	2011	C-600	60600	C-630	60630	C-641	60641	Z
		1997	2003	C-600	60600	C-630	60630	C-637	60637	Z
		1980	1996	C-600	60600	C-630	60630	C-636	60636	Z,1
	Heritage Edition Only	2004	2004	C-600	60600	C-630	60630	C-637	60637	Z
F-250LD	All	1997	2003	C-600	60600	C-630	60630	C-637	60637	Z
F-250 & F-350 Super Duty	Including Air Bag Overloads	2011	2011	C-600	60600	C-630	60630	-	60644	Z,3
		1999	2010	C-600	60600	C-640	60640	-	60644	Z,3
		1999	2010	C-600	60600	C-640	60640	C-643*	60643*	Z,3
F-250 & F-350	Without Overload Springs	1980	1998	C-600	60600	C-630	60630	C-636	60636	Z
	With Overload Springs	1980	1998	C-600	60600	C-630	60630	C-636	60636	
F-450 Super Duty	All, Except Cab & Chassis	2008	2011	C-600	60600	C-640	60640	-	60644	Z,3
		2008	2010	C-600	60600	C-640	60640	C-643*	60643*	Z,3
NISSAN										
Titan	Long & Short Beds	2004	2011	C-620	60620	NYA	NYA	C-664	60664	Z,1
TOYOTA										
Tundra	6' 5" Bed Only	2007	2011	C-600	60600	NYA	NYA	C-667	60667	Z,5
	All Beds	2000	2006	C-625	60625	NYA	NYA	C-665	60665	Z,6

*While Supplies Last

600 Series Footnotes:

- 1 = Passenger side wheel well must be notched for frame rail access
- 2 = Parking brake cable bracket may require relocation
- 3 = Exhaust may have to be permanently lowered on 05 & newer models.
- 4 = Vacuum canister requires relocation (kit included)
- 5 = Ball cannot be turned over, brake lines must be cable tied (ties included)
- 6 = Do not invert ball with heavy loads on 2 wheel drive models
- Z = No frame drilling required

All Models: Brake, fuel, and electrical lines may need to be loosened or repositioned. Heat shield requires modification or removal

30 & 40 Series Installation Kits (30K Gross Towing Weight)

Make/Model	Style	Years From	Years To	Old Double-Lock Hitch#	New Double-Lock Hitch#	Old Quick Goose2 Hitch#	New Quick Goose2 Hitch#	Old Rail Kit#	New Rail Kit#	Notes
CHEVROLET/GMC										
1500, 1500HD, 2500LD, 2500HD Silverado/Sierra	Classic Body Only	1999	2007	C-60	63060	C-300	N/A	C-34	63234	7
3500 Silverado	Classic Body Only	2001	2007	C-60	63060	C-300	N/A	C-32	63232	7
2500 & 3500	Old Body Style	1999	2000	C-60	63060	C-300	N/A	C-31	63231	Z,8
Full Size Pickup Trucks	Not 34" Frame (O.D.)	1988	1998	C-60	63060	C-300	N/A	C-31	63231	Z,8
DODGE										
Ram 1500	All	2002	2008	C-60	63060	C-300	N/A	C-33	63233	9
		1994	2001	C-60	63060	C-400	N/A	C-35	63235	Z
Ram 2500 & 3500	All, Including Mega Cab	2003	2008	C-60	63060	C-300	N/A	C-45	63245	
		1994	2002	C-60	63060	C-400	N/A	C-35	63235	Z
FORD										
F-150	All	2004	2008	C-60	63060	C-300	N/A	C-41	63241	Z
		1997	2003	C-60	63060	C-300	N/A	C-37	63237	9
		1980	1996	C-60	63060	C-300	N/A	C-36	63236	Z
	Heritage Edition Only	2004	2004	C-60	63060	C-300	N/A	C-37	63237	Z
F-250LD	All	1997	2003	C-60	63060	C-300	N/A	C-37	63237	Z
F-250 & F-350 Super Duty	Includes Air Bag Overloads	1999	2008	C-60	63060	C-300	N/A	C-42	63242	9
F-250 & F-350	Without Overload Springs	1980	1998	C-60	63060	C-300	N/A	C-36	63236	Z
	With Overload Springs	1980	1998	C-60	63060	C-300	N/A	C-36	63236	9
F-450	All, Except Cab & Chassis	2008	2008	C-60	63060	C-300	N/A	C-42	63242	9

30 & 40 Series Footnotes:

- 7 = Cut or remove heat shield, drill (2) 1/2" holes/side
- 8 = Relocate brake lines on driver side
- 9 = Remove heat shield, drill (2) 1/2" holes/side, tire removal
- Z = No frame drilling required

All Models: Brake, fuel, and electrical lines may need to be loosened or repositioned. Heat shield requires modification or removal