

INSTALLATION INSTRUCTIONS AND PARTS LIST

APPLICATION:

MODEL 400932 STEP BRACKETS:

2009 DODGE RAM 1500 QUAD/CREW CAB PICKUPS

2010 DODGE RAM HD CREW/MEGA CAB PICKUPS



1. READ INSTRUCTIONS COMPLETELY AND CHECK TO MAKE SURE THAT ALL REQUIRED PARTS (LISTED ON THE SERVICE PARTS LIST) ARE ON HAND BEFORE STARTING THE INSTALLATION.
2. ATTACH THE MOUNTING BRACKETS TO THE VEHICLE AS FOLLOWS: [SEE FIG. 1]
 - 2.1 ON THE VERTICAL WALL OF THE ROCKER PANEL, INSTALL THE T-BOLT WELMENT (ITEM #2) INTO THE LARGE OBOURND HOLE AND FISH THE OTHER END THROUGH THE FORWARD 1/2" HEXAGON HOLE **BE CAREFULL NOT TO DROP THE T-BOLT INSIDE OF THE ROCKER PANEL.** ATTACH THE FLAT NYLON WASHER (ITEM #4) TO THE THREADED END OF EACH BOLT. (THIS IS TO BE USED AS A RETAINER.)
 - 2.2 POSITION THE MOUNTING BRACKET (ITEM #1) SO THAT THE HOLES IN THE BRACKETS LINE UP WITH THE THREADED STUDS ON THE INSIDE WALL OF THE ROCKER PANEL. INSTALL THE 3/8-16 SERRATED FLANGE NUTS (ITEM #3). TIGHTEN BRACKET FASTENERS TO 19 LB FT.
 - 2.3 ASSEMBLE THE DOUBLE ENDED STUD & FASTENERS TO THE BRACKETS AS FOLLOWS:
 - 2.4 INSTALL 3/8" SERRATED FLANGE NUTS (ITEM #3) BACKWARDS, TO THE END OF THE THREAD, ON EACH END OF THE DOUBLE ENDED STUD (ITEM #6).
 - 2.5 ON (1) THREADED END OF THE STUD, INSTALL A 3/8" FLAT WASHER (ITEM #7) AND THEN PUSH THE 3/4" THICK RUBBER WASHER (ITEM #5) AND FLAT WASHER TIGHT UP AGAINST THE SERRATED FLANGE NUT. **(THE END OF THE DOUBLE ENDED STUD SHOULD BE RECESSED BACK IN THE HOLE OF THE RUBBER WASHER APPROXIMATELY 3/16").**
 - 2.6 INSTALL THE SECOND THREADED END OF THE STUD ASSEMBLY THRU THE HOLE IN THE BRACKET (ITEM# 1) AS SHOWN AND INSTALL A 3/8" SERRATED FLANGE NUT. (FINGER TIGHT ONLY).
 - 2.7 POSITION SNUG AGAINST FRAME RAIL AND TIGHT ALL FASTENERS. THIS WILL REINFORCE THE STEP.
3. ATTACHING THE STEP ASSEMBLY:
PLEASE REVIEW THE INSTALLATION INSTRUCTIONS THAT ARE INCLUDED IN YOUR STEP ASSEMBLY FOR SPECIFIC DETAILS.

SERVICE PARTS LIST

ITEM	PART NO.	QTY	DESCRIPTION
PARTS INCLUDED IN THE BRACKET PACKAGE			
1	551656	6	MOUNTING BRACKET, BLK, DODGE, GRIP STEP
2	550147	6	T-BOLT WELDMENT, ZP
3	100181	30	NUT-SERRATED FLANGE,HEX,3/8-16,ZP
4	108442	12	WASHER-NYLON,.360 X 1.50 X .032
5	102592	6	WASHER -RUBBER,.354 X 1.00 X .748
6	551899	6	STUD DBL THREADED,3/8-16 X 11.00,ZP
7	100062	6	WASHER-FLT,3/8,ZP



1200 E. Birch St.

Brandon, SD 57005

REVISION B 05MAR12
REVISION A 20JAN11
551860 SHEET 1 OF 2 09JUN10

SERVICE PARTS LIST

MODEL NO. - 400932




FIG. 1

LOVERNE
A LUVORNE Company
1200 E. Birch St. | Des Moines, IA 50319

REVISION B 05MAR12
REVISION A 20JAN11
551860 SHEET 2 OF 2 28SEP10